


# SUNVISION PRO 28LXT CANOPY



LL = LEFT LAMPHOLDER  
 B = BALLAST  
 F = FAN  
 R = RELAY (CONTACTOR)  
 TB = TERMINAL BLOCK

RL = RIGHT LAMPHOLDER  
 C = CAPACITOR  
 P = POWER  
 T = TIMER  
 S = SWITCH

TLL = TURBO LEFT LAMPHOLDER  
 TRL = TRUBL RIGHT LAMPHOLDER  
 FTB = FACE TANNER BALLAST  
 F = FUSE




6220 CHURCHMAN BYPASS  
 INDIANAPOLIS, IN 46203

22212 REV. A

# SUNVISION PRO 28LXT CANOPY

NOTE:  
1. WIRE COLORS MAY NOT BE EXACTLY AS SHOWN.




TLL = TURBO LEFT LAMPHOLDER  
 TRL = TURBO RIGHT LAMPHOLDER  
 FTB = FACE TANNER BALLAST  
 S = SWITCH

LL = LEFT LAMPHOLDER  
 B = BALLAST  
 F = FAN  
 R = RELAY (CONTACTOR)  
 TB = TERMINAL BLOCK

RL = RIGHT LAMPHOLDER  
 C = CAPACITOR  
 P = POWER  
 T = TIMER

**WARNING : ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN, WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.**

# SUNVISION PRO 28LX BENCH



LL = LEFT LAMPHOLDER  
 B = BALLAST  
 F = FAN  
 HC = HOUR COUNTER

RL = RIGHT LAMPHOLDER  
 C = CAPACITOR  
 P = POWER JACK

FRONT OF BED




6220 CHURCHMAN BYPASS  
 INDIANAPOLIS, IN 46203

22207 REV. A

# SUNVISION PRO 28LX BENCH

NOTE :  
1. WIRE COLORS MAY NOT BE EXACTLY AS SHOWN



LL = LEFT LAMPHOLDER  
B = BALLAST  
F = FAN  
HC = HOUR COUNTER

RL = RIGHT LAMPHOLDER  
C = CAPACITOR  
P = POWER JACK

**WARNING : ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN, WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.**