


SUNVISION PRO 28LX2F CANOPY



f = FUSE
 B = BALLAST
 F = FAN
 R = RELAY (CONTACTOR)
 TB = TERMINAL BLOCK
 S = SWITCH
 LL = LEFT LAMPHOLDER

FB = FACE TANNER BALLAST
 C = CAPACITOR
 P = POWER
 T = TIMER
 ST = FACE TANNER STARTER
 FT = FACE TANNER
 RL = RIGHT LAMPHOLDER

FRONT OF BED

FACE
 TANNER
 SWITCH




6220 CHURCHMAN BYPASS
 INDIANAPOLIS, IN 46203

22214 REV. C

SUNVISION PRO 28LX2F CANOPY

NOTE:
1. WIRE COLORS MAY NOT BE EXACTLY AS SHOWN




LL = LEFT LAMPHOLDER
B = BALLAST
F = FAN
R = RELAY (CONTACTOR)
TB = TERMINAL BLOCK
S = SWITCH
f = FUSE

RL = RIGHT LAMPHOLDER
C = CAPACITOR
P = POWER
T = TIMER
ST = FACE TANNER STARTER
FT = FACE TANNER
FB = FACE TANNER BALLAST

WARNING : ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN, WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.

SUNVISION PRO 28LX BENCH



LL = LEFT LAMPHOLDER
 B = BALLAST
 F = FAN
 HC = HOUR COUNTER

RL = RIGHT LAMPHOLDER
 C = CAPACITOR
 P = POWER JACK

FRONT OF BED




6220 CHURCHMAN BYPASS
 INDIANAPOLIS, IN 46203

22207 REV. A

SUNVISION PRO 28LX BENCH

NOTE :
1. WIRE COLORS MAY NOT BE EXACTLY AS SHOWN



LL = LEFT LAMPHOLDER
B = BALLAST
F = FAN
HC = HOUR COUNTER

RL = RIGHT LAMPHOLDER
C = CAPACITOR
P = POWER JACK

WARNING : ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN, WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.