

Operating instructions Model-No.: JK 126 / 42-4 HT & JK 126 / 42-4 HT AC Ergoline Inspiration 550 Hybrid Technology Ergoline Planet Fitness 42/4 Hybrid Light Technology

1019103-00 / us / 01.2019



US

Contact information

Customer Service



JK Products & Services

411 West Washington Avenue Suite B Jonesboro, Arkansas 72401 800-445-0624 870-935-9046

http://support.jkamerica.com

Manufacturer



JK-Products GmbH Rottbitzer Str. 69

53604 Bad Honnef GERMANY Tel.: +49 (0) 22 24 / 818-140

Fax: +49 (0) 22 24 / 818-166

	A WARNING!
•	Read these operating instructions.
	Failure to observe these instructions:
	 may result in serious injury and death,
WARNING!	 can result in damage to the device and the environment.
	 For the safety of yourself and others, read and observe all instructions contained herein before operating the device.
	 Please make the instructions and additional information available to anyone who operates or services the de- vice.

Copyright

The copyright remains with JK-Holding GmbH.

The contents may not be duplicated (in whole or part), distributed or utilized for competition purposes without authorization or disclosed to other parties.

The right to make technical changes in regard to the figures and information contained in this instruction manual is reserved!



NOTE

The illustrations and texts apply to Ergoline Inspiration 550 and Ergoline Planet Fitness 42/4, even if only one is shown.

1 Table of Contents

2	What certain words and signs mean (Glossary)	6
2.1	Definitions	6
2.2	Warning signs	7
2.3	Symbols on the device	9
3	What this device is	11
3.1	Guidelines	11
3.2	Export	
3.3	Scope of delivery	
3.3.1	Optional	11
3.4	Device description	12
3.5	Options	14
3.6	Function description	16
3.7	Transport	16
3.8	Installation location	
3.8.1	Ventilation	
3.8.2	Setup location	
3.8.3	Commissioning	
3.9	Signs and stickers on the device	
3.10	Technical data	
3.10.1	Power rating, electrical specifications and noise level	
3.10.2	Dimensions	
3.10.3	Lamp configuration	
3.10.4	Accent lighting	
3.10.5	Spare parts	
4	Why you use it	35
4.1	Intended use	
4.2	Skin condition	35
5	Who cannot use it	36
5.1	Prohibited usage	36
5.1.1	Tanning system/Beauty system	36
5.1.2	Vibra Shape (vibration plate)	
6	What you must do to avoid serious harm	37
6.1	General	
6.2	Tanning system	
6.3	Sensor	
7	What you must do to avoid other harm	
7.1	General	
7.2	Tanning system	
7.3	Sensor	

7.4	Vibra Shape (vibration plate)	39
7.5	Foreseeable misuse	40
7.6	Obligations of the studio operator	40
7.7	Staff training	40
8	Risks of using this device	41
9	Benefits of using this device	42
10	How to decide to use this device	43
11	What to do before the treatment	44
12	How to use this device	45
12.1	How to set this device up	45
12.2	How to make sure the device works	45
12.3	How to use it to treat your condition	45
12.4	How to choose correct treatment regimen	45
12.4.1	Skin types	45
12.4.2	Tanning times	46
12.5	How to operate the device	47
12.5.1	Control Center	47
12.5.2	User settings overview	47
12.6	Functions	48
12.6.1	Navigation	49
12.6.2	Description	50
12.7	Operating display of the sensor	50
12.8	Selection of the application	51
12.9	Sun Select setting with the outer interface	51
12.10	Measurement (automatic mode)	51
12.11	Connections	52
12.12	How to use	53
12.12.1	How to start	53
12.12.2	Application tips	53
12.12.3	How to stop	54
12.13	What to do after the treatment	54
12.13.1	Cleaning and disinfection	54
12.14	Safety instructions for cleaning/disinfection and maintenance	55
12.15	How to clean/disinfect	58
12.15.1	Cleaning and disinfection of surfaces	58
12.15.2	Cleaning/disinfection plan	60
12.16	How to maintain	61
12.16.1	Technical modifications	61
12.16.2	Maintenance plan	61
12.16.3	Cleaning and maintenance work preparation	63
12.16.4	Instructions for replacing the lamps	68
12.16.5	Cleaning and disinfection of the sensor	72

12.16.6	Cleaning or replacing lamps in the base	72
12.16.7	Cleaning or replacing the lamps in the side section	73
12.16.8	Cleaning or replacing lamps in the canopy	73
12.16.9	Cleaning or replacing the lamps and	
	filter panels in the shoulder tanner	
12.16.10	Cleaning or replacing the interior lights	74
12.16.11	Cleaning or replacing the canopy accent lighting	75
12.16.12	Cleaning or replacing the front panel accent lighting	75
12.16.13	Cleaning the filters in the base	75
12.16.14	Cleaning the filter mat in the canopy	76
12.16.15	Cleaning the filter mats in shoulder tanner	77
12.16.16	Air conditioning (optional): Empty the condensation tank and clean the filter	77
12.16.17	AQUA / AROMA SYSTEM maintenance	80
12.17	How to store the device	80
12.17.1	Decommissioning	80
12.17.2	Storage	80
12.17.3	Disposal	80
13	What to do when things go wrong	82
13.1	Troubleshooting	83
14	Where you can find out more	84
17		
15	How we studied this device	
		85
15	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC:	85 86
15 16 16.1	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information	85 86
15 16	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC:	85 86 86
15 16 16.1	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information Table 201: Guidelines and manufacturer's declaration – Electromagnetic emissions Table 202: Guidelines and manufacturer's declaration –	85 86 86
15 16 16.1 16.1.1	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information Table 201: Guidelines and manufacturer's declaration – Electromagnetic emissions Table 202: Guidelines and manufacturer's declaration – Electromagnetic interference Table 204: Guidelines and manufacturer's declaration –	85 86 86 86
15 16 16.1 16.1.1 16.1.2 16.1.3	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information Table 201: Guidelines and manufacturer's declaration – Electromagnetic emissions Table 202: Guidelines and manufacturer's declaration – Electromagnetic interference Table 204: Guidelines and manufacturer's declaration – Electromagnetic interference	85 86 86 86
15 16 16.1 16.1.1 16.1.2	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information Table 201: Guidelines and manufacturer's declaration – Electromagnetic emissions Table 202: Guidelines and manufacturer's declaration – Electromagnetic interference Table 204: Guidelines and manufacturer's declaration – Electromagnetic interference Table 206: Recommended safe distances between	85 86 86 86
15 16 16.1 16.1.1 16.1.2 16.1.3	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information Table 201: Guidelines and manufacturer's declaration – Electromagnetic emissions Table 202: Guidelines and manufacturer's declaration – Electromagnetic interference Table 204: Guidelines and manufacturer's declaration – Electromagnetic interference	85 86 86 86 87 88
15 16 16.1 16.1.1 16.1.2 16.1.3	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information Table 201: Guidelines and manufacturer's declaration – Electromagnetic emissions Table 202: Guidelines and manufacturer's declaration – Electromagnetic interference Table 204: Guidelines and manufacturer's declaration – Electromagnetic interference Table 206: Recommended safe distances between portable and mobile HF communications equipment and	85 86 86 86 87 88 88
15 16 16.1 16.1.1 16.1.2 16.1.3 16.1.4	How we studied this device Appendix JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information Table 201: Guidelines and manufacturer's declaration – Electromagnetic emissions Table 202: Guidelines and manufacturer's declaration – Electromagnetic interference Table 204: Guidelines and manufacturer's declaration – Electromagnetic interference Table 204: Guidelines and manufacturer's declaration – Electromagnetic interference Table 206: Recommended safe distances between portable and mobile HF communications equipment and JK 126 / 42-4 HT & JK 126 / 42-4 HT AC	85 86 86 87 88 89
 15 16 16.1 16.1.1 16.1.2 16.1.3 16.1.4 17 	 How we studied this device	85 86 86 86 87 88 89 90 91
 15 16 16.1 16.1.1 16.1.2 16.1.3 16.1.4 17 17.1 	 How we studied this device	85 86 86 86 88 88 89 91 91
 15 16 16.1 16.1.1 16.1.2 16.1.3 16.1.4 17 17.1 17.2 	 How we studied this device	85 86 86 86 87 88 89 90 91 92 92
 15 16 16.1 16.1.1 16.1.2 16.1.3 16.1.4 17 17.1 17.2 17.2.1 	 How we studied this device	85 86 86 86 87 88 89 91 91 91 92 93

2 What certain words and signs mean (Glossary)

2.1 Definitions

Studio operator

People who provide tanning devices to users on a commercial basis. The studio operator is trained to operate and maintain the device and is responsible for the orderly operation of the device as well as compliance with the maintenance intervals.

User

A person who uses the tanning device at a commercial location.

Staff

People who are responsible for the operation, cleaning/disinfection as well as general maintenance work and who instruct the users in the operation of the devices.

JK Factory Certified Technician

Level 1

Authorized to perform general maintenance such as replacing lamps, aqua mist, and fragrance containers as well as overall cleaning of the unit.

Level 2

Authorized to perform maintenance and repairs such as replacement of ballast, framed acrylic, electronic circuit boards, and other electrical components.

Level 3

Authorized and trained to utilize JK Products proprietary diagnostic software to adjust operating parameters and perform detailed diagnostics.

Level 4

This individual is uniquely qualified to assess the condition of a unit and make a determination if the device meets the requirements for continued use ten (10) years from the date of manufacture.

Contraindications

Issues where the risk is always greater than the benefit and there are data supporting the risk and benefit relationship.

2.2 Warning signs

Danger notices, nonobservance will lead to death or serious injury:

DANGER!

Type and source of danger, e.g. 'DANGER – High voltage!'

Description of the consequences, e.g. 'You can be killed or injured by an electric shock!'

Countermeasures:

- Disconnect device from power supply before opening.
- Do not reach into the inside with the device switched
 - on.

Warning notices, nonobservance can lead to death or serious injury.

WARNING!



Type and source of danger, e.g. 'WARNING – hot surface!'

Description of the consequences, e.g. 'You can burn your hand (skin, face)!'

Countermeasures:

- Do not touch hot parts and nearby surfaces.
- Wait until hot parts and surfaces have cooled down.

Warning notices, ultraviolet radiation, nonobservance can lead to serious injury:

WARNING!



Type and source of danger, e.g. 'WARNING – ultraviolet radiation!'

Description of the consequences, e.g. 'You can burn your skin!'

Countermeasures, e.g.:

- Avoid overexposure.

WARNING!



Crushing hazard, e.g. when closing the bed base! Fingers can be jammed.

Do not hold fingers between bed base and front panel.

Caution notices, nonobservance can lead to less than serious injury or damage of property.



Unauthorized lamps!

The word 'Caution' together with the warning sign points out that less than serious injury can be expected here. Countermeasures:

ountenneasures.

Avoid doing this.



ESD-sensitive components!

NOTICE

The word 'NOTICE' without warning sign points out that danger for devices, materials and the environment can be expected here.

Countermeasures:

Avoid doing this.

Important information:



NOTE:

This symbol does not identify safety notices, but states information for a better understanding of the processes.


2.3 Symbols on the device

The following symbols are displayed on the device:

Manufacturer, company address

Type BF applied part¹

Follow Operating Instructions.



Where there are great differences in temperature between the transport route and the installation site the device may not be put into operation immediately after being set up.

Wait at least 2 hours before connecting the device to the power supply.



Maximum transport weight



Do not stack!



This side up.



Keep dry.



Temperature limitations. The temperature limits are noted next to the upper and lower horizontal line.

¹ Devices with physical contact between device and user belong to category BF (body float).



Recyclable material.

Production year, month and day

Qty:

Quantity

- **REF** Article Number/Reference Number
- **SN** Serial Number
- + UDI
- HIBC

Healthcare Barcode

Unique Device Identification



Polystyrene



Cardboard



Mixed paper



Steel





Permitted air pressure during transport and storage.

3 What this device is

3.1 Guidelines

This product is in conformity with the performance standards for sunlamp products under 21 CFR 1040.20, FDA and listed with ETL to UL 482 and CAN/CSA 22.2 No. 224.

3.2 Export

This device is exclusively intended for use in the USA and Canada and may not be exported to other countries and operated there! The manufacturer assumes no liability whatsoever in the event of non-compliance. High liability risks may occur for the exporter and/or the studio operator in the event of noncompliance.

3.3 Scope of delivery


- Tanning device
- Lamps
- Service kit including an Allen-key and suction cup for filter panels
- Protective goggles
- Technical documentation (folder with instructions, brochures for error codes and default settings and additional documentation)

3.3.1 Optional


- Central exhaust air socket
- Audio system (with Voice Guide)

3.4 Device description

Ergoline Inspiration 550 Hybrid Technology



- 1. Facial tanner (UV high pressure lamps + low pressure lamps)
- 2. Audio system (optional)
- 3. Low pressure lamps, base
- 4. Acrylic panel base
- 5. Partition
- 6. Low pressure lamps, canopy
- 7. Interior lighting
- 8. Body cooling air nozzles
- 9. Adjustable air nozzles Facial cooling
- 10. Operating panel
- 11. Accent lighting, canopy
- 12. Accent lighting, front panel




Ergoline Planet Fitness 42/4 Hybrid Light Technology

- 1. Facial tanner (UV high pressure lamps + low pressure lamps)
- 2. Audio system (optional)
- 3. Low pressure lamps, base
- 4. Acrylic panel base
- 5. Partition
- 6. Low pressure lamps, canopy
- 7. Interior lighting
- 8. Body cooling air nozzles
- 9. Adjustable air nozzles Facial cooling
- 10. Operating panel
- 11. Accent lighting, canopy
- 12. Accent lighting, front panel


3.5 Options

Ergoline Inspiration 550 Hybrid Technology



- 1. Central exhaust air socket
- 2. Audio system (with Voice Guide)
- 3. Headphone connection
- 4. AUX connection

Ergoline Planet Fitness 42/4 Hybrid Light Technology



17927 / 0

- 1. Central exhaust air socket
- 2. Audio system (with Voice Guide)
- 3. Headphone connection
- 4. AUX connection

Exhaust option

As an optional comfort feature, your device can be equipped with an exhaust duct which allows the warm air from the device to be ducted outside of the room or building. Doing so can be an effective way in some climates to reduce the energy costs associated with air conditioning while at the same time increasing not only user comfort, but the environmental comfort of the entire studio as well.

Things to consider before purchasing the exhaust option are:

- Climate; extremely hot climates are typically not a good choice for exhausting air outside due to the need to cool down the hot air coming in to replace the air being exhausted, however mild to cooler climates can benefit from exhausting the warm air from the device thereby allowing cooler air to enter from outside the building.
- 2. Device location; in some installations, walls or other obstruction may prevent the use of an exhaust duct.



NOTE:

- Always consult a licensed heating, ventilation, and airconditioning (HVAC) Technician when considering the option to exhaust the warm air from your device. They can help you decide if an exhaust is best for you specificlocation.
- The exhaust is a comfort option and does not increase or decrease the safety and effectiveness of the device. The exhaust duct is not required to keep the device in a certain temperature range in order to operate safe and effectively.

3.6 Function description

Tanning system


The primary technical components of a tanning device are an artificial source of UV radiation, a variety of filters and reflectors as well as a mechanical structure with a defined active surface.

Different tanning results can be achieved in varying strength tanning devices. This is due to the different strength UV lamps and the different UV-A and UV-B proportions of the UV radiation. The UV-A proportion primarily generates a superficial tan, which appears rapidly and is intensive but also fades more rapidly, the UV-B radiation is primarily responsible for more long-term tanning results.

Traditional UV light with the addition of (beauty) red light results in a natural looking tan. Optimal tanning results are achieved due to the synergistic combination of light spectrums.

3.7 Transport

Tanning system



3.8 Installation location

This sunlamp product is suitable for tanning salons, fitness studios or similar installation locations.

You may find detailed information on installation and setting up in the Installation Instructions (see folder Technical Documentation).

3.8.1 Ventilation


NOTICE

Danger of failure!

Danger of overheating by obstruction of the air routing.

- Observe the ventilation information to avoid serious system malfunctions.

You can obtain data regarding the air supply and ventilation from the customer service department (see page 2).



Setup location 3.8.2 WARNING!



Sudden movements and malfunctions!

Crushing hazard.

WARNING!

The device is not suitable for operation in mobile facilities (ships, buses, trains). Adaptation of the unit is required in order to guarantee trouble-free operation when used in mobile facilities.

A CAUTION!



Danger of overheating by obstruction of the air routing!

Any liability is excluded in case of damage or injury proven to be the result of the use of non-genuine spare parts.

Use of non-compliant lamps voids warranty and risks injury!

- Do not change, obstruct or block the air inflow and outflow area to the device or make any unauthorized changes to the device. The manufacturer shall bear no liability for damage or injuries resulting from such actions.
- Observe the ventilation information to avoid serious system malfunctions.
- Before putting a device into operation, the transport pallet must be removed from under the device. Danger of overheating by obstruction of the air routing.
- Maintain the minimum distances from the walls! Dimensions are given on page 30.
- Only use OEM spare parts of the same type! The use of other parts will void the manufacturer's warranty!

NOTICE

Salty air! Contaminated air!

Device damage due to corrosion of the housing and electrical components.

- Do not install the device near swimming pools.
- Do not operate the device in locations with aggressive environmental conditions (e.g. air containing chlorine).


Damage to the device possible!

Where there are great differences in temperature between the transport route and the installation site the device may not be put into operation immediately after being set up.

Wait at least 2 hours before connecting the device to the power supply.

Damage to the device possible!

The device is not to be used outdoors.



Environmental conditions

- Optimum ambient temperature: between 59 °F (15 °C) and 89.6°F (32°C)
- Storage temperature: between 5 °F (-15 °C) and 140 °F (+60 °C)
- Air pressure: between 794 hPa and 1060 hPa
- Relative humidity: between 30 % and 70 %

Please contact the customer service department before putting the device into operation - see page 2.

3.8.3 Commissioning

	A DANGER!
Λ	Damaged mains power cable!
14	Danger to persons through electric shock or burns.
DANGER!	 Only the manufacturer or specialist companies are permitted to replace the mains power cable.

Initial commissioning will be undertaken by the manufacturer's own service personnel or by a (Level 3) JK Factory Certified Technician. The device will be handed over ready for use.


As the studio operator you are responsible for abiding by the electrical regulations applicable at the installation site.

The unit incorporates special preventive measures with regard to the electromagnetic compatibility and must be installed and commissioned according to the EMC instructions obtained from the assembly instructions.


If the device has not been operated or serviced for a period of one year or longer, it must first be inspected by a (Level 3) JK Factory Certified Technician before being put back into operation. Failure to do so may result in personal injury or property damage.

3.9 Signs and stickers on the device

Signs which warn of danger areas or give important information on components are attached to the device. Ensure that the instruction signs are always clearly recognizable and easily legible. Any missing instruction signs or stickers must be replaced.




1: Name plate (example)



The name plate is attached to the interior side of the canopy. It contains important information for identifying the device (e. g. the serial number = Serial-No.) and the conformity mark.

2: UDI plate (example)




18153 / 0

3: Standards

THIS PRODUCT IS IN CONFORMITY WITH PERFORMANCE STANDARDS FOR SUNLAMP PRODUCTS UNDER 21CFR PART 1040.20

17292 / 0

4: Warning sticker UV radiation (801140-..)



12076 / 1

5: Sticker 'Follow Operating Instructions' (1014232-..)



6: Age warning label (1508746-..)

ATT	ENTION: THIS SUNLAMP PRODUCT
SHC	DULD NOT BE USED ON PERSONS
UN	DER THE AGE OF 18 YEARS.

17303 / 0

The sticker is mounted on the front panel.

ACHTUNG! Hier oben! ATTENTION! This side up! Falls Klimagerät gekippt, vor Inbetrieb nahme 8 Stunden in Normalstellung stehen lassen, wegen Rücklaut der Kühltlüssigkeit initiation, because of the return of the refrigerant.
GEFAHR Bei geöffnetem Gerät nicht spannungsfrei! DANGER Voltage is not switched off, when sunbed is opened.
Regelmäßige Sichtprüfung! Regular visual check! Contrôle visuel régulier! Gefahr von Geräteschäden! Risk of damage to equipment! Risque de détérioration de l'appareil!
Abdeckung entlernent Remove cover! Éliminer la couverturet
<text></text>
1:

7: Air conditioning sticker (1002243-..), (option)

The sticker is mounted on the air conditioning.


8: 'Remove lattice' sticker



11978 / 0

The sticker is mounted on the rear panel.

9: Ballast support warning sticker (1003399-..)



HINWEIS!

INIWERSI In diesem Gerät dürfen nur Originalteile von JK-Products GmbH bzw. von JK-Products GmbH freigegebene Teile verwendet werden. Ersatzteile, die die oben genannten Voraussetzungen nicht erfüllen, jedoch den Anspruch erheben, mit obigen Teilen identisch zu sein (Ident-Teile) dürfen grundsätzlich nicht eingebaut werden. Über Ausnahmen im Einzelfall entscheidet die JK-Products GmbH.

WARNHINWEIS!

WARMNINWEISI Der Einbau von nicht frei gegebener Fremdelektronik oder ungenehmigte Änderungen jedweder Art an Konstruktion, Verdrahtung o. ä. führen zum Erlöschen der Gewährleistungsansprüche. Zuwiderhandlungen können Brandgefahren auslösen, durch die Personen infolge Rauchvergiftung und/ oder Feuer getötel oder schwer verletzt werden können. Des Weiteren erlischt die für das Gerät ausgestellte EU-Konformitätserklärung (CE-Kennzeichen). Es besteht ferner die Gefahr, dass Sie die Ansprüche aus der gesetzlichen Produkthaftung verlieren.

NOTE!

Only genuine parts or parts approved by JK-Products GmbH or JK-Products GmbH may be used in this device. Replacement parts that do not meet the above requirements, but which, however, claim to be identical with the above mentioned parts (pattern parts), must not be fitted under any circumstances. JK-Products GmbH will judge exceptions to this on a case by case basis.

WARNING

WARNING! The installation of unapproved electronics made by other manufactures or unapproved changes of any kind to the design, wiring etc. shall result in any and all warranty Claims being forfeited. Non-conformance may result in a **risk of fire**, through which, persons may be killed or badly injured as a result of smoke inhalation or fire. Moreover, the EU

conformity declaration (CE certification) for the unit will be invalidated. There is also a danger of loosing the right to any claims based on legal product liability.


Sicherheitshinweis: Zum störungsfreien Gerätebetrieb muß der Steuerboxdeckel immer ordnungs gemäß verschraubt sein!

Note on safety: The control box cover must always be properly screwed on for fault-free device operation! 100339-00-

17483 / 0

The sticker is mounted on the power unit support.

10: Controller connections sticker (843147-..)




The sticker is mounted on the controller support.

11: Sticker ESD (85662-..)



17486 / 0

The sticker is mounted on several places in the device.



12: USA mains connection sticker (801046-..)

The sticker is mounted on the left side panel.

13: Canada warning sticker (801371-..)

Only for Canada

Caution: Connect only to a circuit protected by a class A ground fault circuit interrupter.

Seulement pour le Canada

Attention: Brancher seulement à une dérivation protégée par un disjoncteur différentiel de classe A. 801371-01-

13514 / 0

The sticker is mounted on the rear panel.

14: Exposure label

DANGER OF ULTRAVIOLET RADIATION.

Follow all instructions. Avoid over-exposure as with natural sunlight. Over-exposure may cause eye and skin injuries, as well as allergic reactions. Repeated exposure may lead to premature aging of skin and skin cancer.

MAXIMUM TANNING TIME: 12 MINUTES

	Recommended Exposure Schedule					\square	
		Week 1	Week 2	Week 3	Week 4	Weekly	L
	Skin Type	1st - 3rd Treatments	4th - 6th Treatments	7th - 10th Treatments	11th - 15th Treatments	Subsequent Treatments	/
	I - Sensitive	NOT ADVISED	NOT ADVISED	NOT ADVISED	NOT ADVISED	NOT ADVISED	
2	II - Fair	2 Min.	5 Min.	8 Min.	10 Min.	12Min.	$\left \right\rangle$
\geq	III - Average	2 Min.	5 Min.	8 Min.	10 Min.	12Min.	
	IV - Brown	2 Min.	7 Min.	10 Min.	12 Min.	12Min.	
	V - Dark Brown	2 Min.	7 Min.	10 Min.	12 Min.	12Min.	\mathbb{K}

1	WEAR PROTECTIVE EYEWEAR! FAILURE TO DO SO MAY
7	RESULT IN SEVERE BURNS OR LONG TERM INJURY TO THE EYES.
7	Certain medications or cosmetics may increase your sensitivity to ultraviolet radiation. Consult a physician before using sunlamps if you are using medications, have a history of skin problems or believe yourself to be especially sensitive to sunlight. If you do not tan in the sun, you are unlikely to tan from the use of this product.

This unit utilizes UV lamps. Replace only with GENESIS Type U and Type R HYBRID Performance 160W, GENESIS Type U and Type R HYBRID Performance 160W and Ergoline ULTRA 520W (hiph-pressure / facial tanner) and GENESIS Type R HYBRID 8W (low-pressure / facial tanner) or other recognized equivalents. To obtain the recommended exposure distance, lie in the middle of the acrylic glass panel and lower the canopy to the closed position.

Warning: The use of any other position may result in overexposure!

[]	Tanning can begin on a regular basis. A tan normally appears after several exposures and is maximized after four (4) weeks of exposure in accordance with the recommended exposure schedule for your skin type. In order to maintain your tan, a maximum of two (2) weekly 12 minute sessions is recommended from the fith week orward. Do not tan more than once in a 24-hour period.	Use protective eyewear (Super Sunnies®) whenever the unit is in operation. Read and follow the instruction booklet before using this product. To avoid electrical shock during maintenance, disconnect the unit from the power source. This product conforms with the performance standards for sunlamp products under 21 CFR 1040.20, FDA.
		Part No: 1020362-00

19150 / 0

The sticker is mounted on the lamp cover foot end.

15: Sticker (1014367-..)

FOR SALES, SERVICE, LAMPS & LOTIONS CALL: 800.643.0086 www.jkamerica.com

17197 / 0

16: Lamp cover base sticker (801139-..)

 CAUTION - RISK OF PERSONAL INJURY
 ATTENTION - RISQUE DE BLESSURE

 UV LIGHT SOURCE - KEEP PROTECTIVE BARRIER IN PLACE
 SOURCE DE RAYONS UV - NE PAS ENLEVER L'ECRAN

 Keep protective barrier in place or replace removable parts after servicing.
 Repas enlever l'ecran protecteur ou remettre en place les pieces amovibles apres l'entretien.



The sticker is mounted on the lamp cover foot end.

17: Warning sticker crushing hazard (1015567-..)



18: OEM parts sticker (801138-..)

ATTENTION!

Only use OEM certified replacement parts. The use of other parts voids all manufacturer's warranties and responsibilities.

13513 / 0

The sticker is mounted on the bottom of the bed base.

19: AQUA MIST sticker (801211-..) Not applicable for this device.

20: Sticker ESD/Aquamist (1000791-..) Not applicable for this device.

21: Sticker Chip card (843148-..) Not applicable for this device.

22: Warning sticker sensor base station (1009643-..) Not applicable for this device.

3.10 Technical data

3.10.1 Power rating, electrical specifications and noise level

JK 126 / 42-4 HT AC			
Power consumption rating:		11,200 W	
Rated frequency:		60 Hz	
Rated voltage:	230 V 3 phase		230 V 2 phase
Rated fuses:	40 amp 3-pole		80 amp 2-pole
Classification:		Type BF applied part lying surface (PMMA)	
Power supply:	4 x THHN AWG 10		7 x THHN AWG 10
Ingress protection classification:		IP20	
Protection against electric shock:		Class I	
Max. allowed network impedance:		0.095 Ω	
Noise level 1m away from device (without exhaust air):		66.4 dB(A)	
Noise level inside the device:		< 70 dB(A)	
Load on the acrylic panel:		max. 330 lb/150 kg	
Weight:		approx. 1,211 lb/549 k	g
Max. humidity:		< 70%	
Ambient temperature:		59-89 °F (15-32 °C)	
Max. operating altitude (above sea level):		< 6,500 ft (2,000 m)	

JK 126 / 42-4 HT			
Power consumption rating:		10,000 W	
Rated frequency:		60 Hz	
Rated voltage:	230 V 3 phase		230 V 2 phase
Rated fuses:	40 amp 3-pole		60 amp 2-pole
Classification:		Type BF applied part lying surface (PMMA)	
Power supply:	4 x THHN AWG 10		7 x THHN AWG 10
Ingress protection classification:		IP20	
Protection against electric shock:		Class I	
Max. allowed network impedance:		0.095 Ω	
Noise level 1m away from device (without exhaust air):		68.1 dB(A)	
Noise level inside the device:		< 70 dB(A)	
Load on the acrylic panel:		max. 330 lb/150 kg	
Weight:		approx. 1,190 lb/540 kg	9
Max. humidity:		< 70%	
Ambient temperature:		59-89 °F (15-32 °C)	
Max. operating altitude (above sea level):		< 6,500 ft (2,000 m)	



NOTE:

Adaptation of the unit is required for operating altitudes greater than 6,500 ft / 2,000 m above sea level in order to guarantee trouble-free operation.

Essential performance:




NOTE:

The essential performance of the device is the UV exposure dose within specified limits, whereas the upper limit must not be exceeded. No-radiation or zero radition does not result or contribute to an injury of the user.

Lower limit	exposure dose 0,75 MED*)
Upper limit	exposure dose 4 MED*)

^{*)} in compliance with 21 CFR 1040.20 and FDA's timer policy




B - =

3.10.3 Lamp configuration



The use of other lamps and filter panels voids the operating license!

JK 126 / 42-4 HT & JK 126 / 42-4 HT AC




Lamp set

1	Numbe	r Description	Length	Power	Control	Order-no.
a)	4	UV high pressure lamps Ergoline ULTRA 520 W Filter panels Ultra Performance 862H		520 W	400 W / 320 W	12645 1004204
L.)		•	0.04	0.144	0.14/	
b)	3	UV low pressure lamps Genesis Type R Hybrid 8W	0.31 m	8 W	8 W	1510958
	3	Starter S10 (4-65 W)				10047
c)	18	UV low pressure lamps Genesis Type U HYBRID Performance 160W	1.80 m	160 W	160 W	1510951
d)	8	Low pressure lamps Genesis Type R HYBRID Performance 160W	1.80 m	160 W	160 W	1510952
e)	10	UV low pressure lamps Genesis Type U HYBRID Performance 180W	2.00 m	180 W	180 W	1510953
f)	6	Low pressure lamps Genesis Type R HYBRID Performance 180W	2.00 m	180 W	180 W	1510954

3.10.4 Accent lighting


Ergoline Inspiration 550 Hybrid Technology



17776 / 0

	Number	Description	Power	Order-no.
d)	1 1 1	Low pressure lamp yellow Makrolon tube orange Starter S10 (5-65 W)	36 W	1005095 1016387 10047
e)	1 1 1	Low pressure lamp red Makrolon tube yellow Starter S10 (5-65 W)	36 W	12968 1016385 10047
f)	1 1 1	Low pressure lamp red Makrolon tube yellow Starter S10 (5-65 W)	36 W	12968 1016385 10047
g)	1 1	Low pressure lamp blue Starter S10 (5-65 W)	36 W	11792 10047


Ergoline Planet Fitness 42/4 Hybrid Light Technology



	Numbe	r Description	Power	Order-no.
g)	2 2	Low pressure lamp daylight (900 mm) Starter S10 (5-65 W)	36 W	1001917 10047
e)	1 1	Low pressure lamp daylight (1200 mm) Starter S10 (5-65 W)	36 W	12969 10047
f)	1 1	Low pressure lamp white (1500 mm) Starter S10 (5-65 W)	38 W	1002089 10047

3.10.5 Spare parts

JK 126 / 42-4 HT & JK 126 / 42-4 HT AC



19083 / 0

	Number	Description	Order-no.
1	1	Partition	1013961
2	4	Filter	52104
3	1	Filter mat	1013452
	1	Protective goggles	84592
	1	AUX cable	1001855
	1	Allen-key	83828

For more spare parts, contact Customer Service (see page 2).

4 Why you use it

4.1 Intended use

This sunlamp product is intended exclusively for cosmetic tanning of the human skin, for one person at a time, at the age of 18 or above.

4.2 Skin condition

You may benefit from the use of this device

- if you tan in natural sunlight (skin types III, IV and V),
- if you have no acute sunburn or skin disease,
- if you take no medication or use cosmetics that may increase sensitivity to ultraviolet light.

Skin type I (Sensitive):

Invariably gets sunburn, accepts little natural sunlight and does not tan.

Skin type II (Fair):

Gets sunburn easily and severely, tans minimally or lightly and peels.

Skin type III (Average):

Often referred to as "Average" complexion, gets moderate sunburns and tans about average.

Skin type IV (Brown):

Seldom gets sunburns, tans easily and above average with each exposure.

Skin type V (Dark Brown):

This individual's skin rarely gets sunburns, tans easily and substantially.



5 Who cannot use it

5.1	Prohibited usage
5.1.1	Tanning system/Beauty system
	UV radiation Danger of skin and eye injuries or skin diseases!

The following people must not use the device:

- People under 18 years of age
- People with skin lesions or open wounds
- People with acute sunburn
- People who repeatedly suffered from serious sunburn during childhood
- People with naturally red hair and pale skin
- People with atypically discolored patches of skin
- People who have or have had skin cancer
- People who suffer from an increased risk of skin cancer (e.g. cases of skin cancer in the family)
- People among whose closest relatives a melanoma has occurred
- People who are being medically treated for photosensitivity
- People taking photosensitivity causing medicine
- · People with freckles and people who tend to develop freckles
- People with more than 16 moles on their body (2 mm diameter or larger)
- People with atypical moles (atypical moles are, for example, asymmetrical moles with a diameter greater than 5 mm, with varying pigmentation and irregular edges)
- Seek medical advice if in doubt!

5.1.2 Vibra Shape (vibration plate)

Not applicable for this device.

6 What you must do to avoid serious harm

6.1 General

▲ DANGER – HIGH VOLTAGE!




You can be killed or injured by an electric shock! Assembly and electrical connection must comply with national and local regulations.

 The device may only be assembled, installed, upgraded or repaired by authorized, trained and qualified staff.

Risk of electric shock!



To avoid risk of electric shock, this equipment must only be connected to a mains supply with protective earth grounding.



The electrical installation must have a freely accessible, all-pole disconnecting device (Master switch with clearly labelled On/Off settings, e.g. '0' and 'l' or additional indicator light) fitted externally on the side.

🔔 DANGER – HIGH VOLTAGE!



You can be killed or injured by an electric shock or injured by overexposure!

Skin damage and sunburn possible

Danger of overheating by obstruction of the air routing.

- No modification of this equipment is allowed.

6.2 Tanning system

WARNING!



Unprotected tanning may result in eye injury and eye diseases!

WARNING! The unprotected eye can become inflamed on the surface, and in certain cases the retina can be damaged by excessive radiation. Cataracts can form after repeated exposure to radiation.

Inform users to use the included protective goggles that block UV.



WARNING!

Danger of ultraviolet radiation.

Ultraviolet radiation - follow instructions.

Failure to use protective eyewear may result in severe burns or other eye injury - if discomfort develops, discontinue use and consult a physician.

- _ As with natural sunlight, overexposure can cause eye injury and sunburn;
- Repeated exposure may cause premature aging of the skin and skin cancer;
- Medications or cosmetics applied to the skin, may increase sensitivity to ultraviolet light;
- A person who does not tan in the sun most likely will not tan from the use of this device:
- A person having a history of skin problems should consult a physician before use;
- Overexposure should be avoided
- Children, the elderly, or fair skinned people who always burn easily and either never tan or tan minimally should not use this equipment.
- The appliance is not allowed to be used by more than one person at the same time.

WARNING!



Danger of long-term consequences! Exposure to ultraviolet radiation may increase the likelihood

of developing skin cancer and cause serious eye injury.

WARNING!

- _ Overexposure should be avoided.
- This sunlamp product should not be used on persons under the age of 18 years.
- Seek medical advice if in doubt!

6.3 Sensor

Not applicable for this device.

7 What you must do to avoid other harm

7.1

General

WARNING!



Infections can be transferred through skin contact. All items/equipment components, with which the user can come into contact during tanning, must be cleaned and

- disinfected after every tanning session:
 - Protective goggles
 Acrylic panels
 - Handles and control panel
 - AUX cable
 - Adjustable air nozzles
 - Use only EPA registered quaternary ammonium germicidal based detergent solution (follow product label for use-dilution), such as Lucasol One Step, to clean and disinfect the tanning system and its components.

7.2 Tanning system

WARNING!



Danger of long-term consequences! – Overexposure should be avoided.

- The elderly should not use this equipment.
- This sunlamp product should not be used on persons under the age of 18 years.
- While there is no immediate clinical evidence of UV exposure and its effects upon expectant mothers, it is strongly advised that expectant mothers be discouraged from using the tanning unit.

7.3 Sensor

Not applicable for this device.

7.4 Vibra Shape (vibration plate)

Not applicable for this device.

7.5 Foreseeable misuse

The following uses of the device are explicitly prohibited:

- Only one person at a time may use the device.
- People with body weight of more than 330 lbs (150 kg) may not use the device.
- Exceeding the specified tanning times may result in burns and long-term skin damage.
- When the device is in use no other people may remain in the room. This includes both children and adults.

7.6 Obligations of the studio operator

- As the studio operator you are responsible for informing users on possible risks of tanning.
- All danger and safety labels attached to the device must be observed! Do not remove them!
- No safety equipment (e.g. panel switch) may be removed, deactivated, or otherwise bypassed as it can impair the safe operation of the device!
- The device may only be used when in completely operational condition!
- It is the studio operator's responsibility to ensure the tanning system is handled properly.

7.7 Staff training

As the operator you are obligated to train your personnel and instruct them in the established legal and accident prevention regulations. Ensure that your staff have understood and observe these instructions. This includes:

- information regarding intended use and foreseeable misuse
- safety instructions
- operating instructions
- cleaning/disinfection and maintenance instructions
- Please make the instructions and additional information from the manufacturer available to the staff at their workplace.
- Regularly check your staff's safety consciousness and awareness of the risks, taking into account your operating instructions.
- Please ensure that the cleaning/disinfection intervals are complied with, in particular cleaning and disinfection after every use.
- Please ensure that your staff provide your customers with appropriate advice, in particular regarding tanning times, possible risks and the operation of the device.

8 Risks of using this device

A WARNING!



Danger through ultraviolet radiation!

Danger of skin and eye injuries or skin diseases!

- This sunlamp product must not be used on individuals who have had skin cancer or have a family history of skin cancer.
- Persons repeatedly exposed to ultraviolet sunlamp products must be evaluated for skin cancer regularly.
- This sunlamp product must not be used by people among whose closest relatives a melanoma has occurred.

Contraindications! The following people must not use this system:

- People under 18 years of age
- People with skin lesions or open wounds
- People with acute sunburn
- People who repeatedly suffered from serious sunburn during childhood
- People with naturally red hair and pale skin
- People with atypically discolored patches of skin
- People who have or have had skin cancer
- People who are being medically treated for photosensitivity
- People taking photosensitivity causing medicine
- People with freckles and people who tend to develop freckles
- People with more than 16 moles on their body (2 mm diameter or larger)
- People with atypical moles (atypical moles are, for example, asymmetrical moles with a diameter greater than 5 mm, with varying pigmentation and irregular edges)

9 Benefits of using this device

This device serves the purpose of aesthetic tanning for one adult person with skin suitable for tanning.

Different tanning results can be achieved in varying strength tanning devices. This is due to the different strength UV lamps and the different UV-A and UV-B proportions of the UV radiation. The UV-A proportion primarily generates a superficial tan, which appears rapidly and is intensive but also fades more rapidly, the UV-B radiation is primarily responsible for more long-term tanning results.

The Ergoline Inspiration 550 Hybrid Technology and Ergoline Planet Fitness 42/4 Hybrid Light Technology gives you a gentle tanning experience.

Traditional UV light with the addition of (beauty) red light results in a natural looking tan. Optimal tanning results are achieved due to the synergistic combination of light spectrums.

10 How to decide to use this device

This device is intended only for commercial use and not for private use.

Some people are not permitted to use the device, see chapter 5.

The device may not be used by people with reduced physical, sensory or mental capabilities or who have insufficient experience and/or knowledge without supervision. A person responsible for their safety must ensure, either by supervision or instruction, that the device is used correctly and safely. If there is any doubt, use of the device by such categories of persons is to be forbidden!

11 What to do before the treatment

Please check for any conditions that may prohibit the use of this device – see chapters 5, 6, 8, 10.

Make-up in the tanning device

Please do not wear make-up. Clean skin absorbs UV light better.

A wide variety of materials is found in cosmetics. Whether these are emulsifiers, greases, or fragrances - in conjunction with UV radiation, these can cause skin allergy reactions.

Remove all make-up. This is essential. Make-up clogs the pores in the face. The UV light from a tanning device re-opens these clogged pores so that not only does the light penetrate the skin, but also the allergenic components of the make-up.

A further negative consequence of make-up is that the appearance of the skin deteriorates irreversibly over a period of time. However good make-up looks - in conjunction with UV light, it causes more harm than good. Therefore remove all make-up before a session in your tanning device - it will be much better applied afterwards.

- Remove all jewelry (including piercings) prior to the application.
- Remove cosmetics before using the device and do not use sun screen products.

Are medications and the tanning device compatible?

It is known that some medications increase the skin's sensitivity to UV light. This probability is particularly high with antibiotics, sulphonamides, psychiatric drugs, tranquillizers, anti-diabetes treatments and diuretics. Sun creams which contain psorale or kumarin also increase skin sensitivity. If you are in any doubt, first ask your doctor.

Contact lenses in the tanning device?

The answer is: Yes! Like any other tanning device user, contact lens wearers should also wear special protective goggles which protect the eyes against UV radiation. To guarantee better protection, wearers of glasses and contact lenses can ask their optician for exchange contact lenses with UV protection.

This will benefit tanning device users not only in the open air, but on the tanning device itself. You can wear these contact lenses on the tanning device without any restrictions. For more information, ask your optician or optometrist.

Showering after leaving the tanning device?

The browning is in the skin, not on it. Therefore you cannot wash it off. Treat your skin to a moisturizing cream after showering.

12 How to use this device

12.1 How to set this device up

After commissioning and cleaning/disinfection, the device is ready for operation.

See chapter 12.5.

12.2 How to make sure the device works

Before using the device, check for damage to filter panels and acrylic panels.

12.3 How to use it to treat your condition

- No other persons are permitted inside the cabin while the device is in use.
- UV light can cause irreversible skin or eye damage. The unprotected eye can become inflamed on the surface, and in certain cases the retina can be damaged by excessive radiation. Cataracts can form after numerous repeated tanning sessions. Use the UV-impermeable protective gog-gles provided (order no. 84592-..). Contact lenses and sun glasses are no substitutes for protective glasses.
- Always comply with the recommended application times.

12.4 How to choose correct treatment regimen

12.4.1 Skin types

Skin type I (Sensitive):

Invariably gets sunburn, accepts little natural sunlight and does not tan.

Skin type II (Fair):

Gets sunburn easily and severely, tans minimally or lightly and peels.

Skin type III (Average):


Often referred to as "Average" complexion, gets moderate sunburns and tans about average.

Skin type IV (Brown):

Seldom gets sunburns, tans easily and above average with each exposure.

Skin type V (Dark Brown):

This individual's skin rarely gets sunburns, tans easily and substantially.



12.4.2

Tanning times



NOTE:

The tanning times given in the table must not be exceeded!

DANGER OF ULTRAVIOLET RADIATION. Follow all instructions. Avoid over-exposure as with natural sunlight. Over-exposure may cause eye and skin injuries, as well as allergic reactions. Repeated exposure may lead to premature aging of skin and skin cancer.

MAXIMUM TANNING TIME: 12 MINUTES

	Recommended Exposure Schedule						
		Week 1	Week 2	Week 3	Week 4	Weekly	L
	Skin Type	1st - 3rd Treatments	4th - 6th Treatments	7th - 10th Treatments	11th - 15th Treatments	Subsequent Treatments	
	I - Sensitive	NOT ADVISED	NOT ADVISED	NOT ADVISED	NOT ADVISED	NOT ADVISED	
2	II - Fair	2 Min.	5 Min.	8 Min.	10 Min.	12Min.	$\left \right\rangle$
\geq	III - Average	2 Min.	5 Min.	8 Min.	10 Min.	12Min.	
	IV - Brown	2 Min.	7 Min.	10 Min.	12 Min.	12Min.	
	V - Dark Brown	2 Min.	7 Min.	10 Min.	12 Min.	12Min.	\leq

WEAR PROTECTIVE EYEWEAR! FAILURE TO DO SO MAY RESULT IN SEVERE BURNS OR LONG TERM INJURY TO THE EYES.

Certain medications or cosmetics may increase your sensitivity to ultraviolet radiation. Consult a physician before using sunlamps if you are using medications, have a history of skin problems or believe yourself to be especially sensitive to sunlight. If you do not tan in the sun, you are unlikely to tan from the use of this product. This unit utilizes UV lamps. Replace only with GENESIS Type U and Type R HYBRID Performance 160W, GENESIS Type U and Type R HYBRID Performance 180W and Ergoline ULTRA 520W (high-pressure / facial tanner) and GENESIS Type R HYBRID 8W [low-pressure / facial tanner) or other recognized equivalents. To obtain the recommended exposure distance, lie in the middle of the acrylic glass panel and lower the canopy to the closed position.


Warning: The use of any other position may result in overexposure!


Tanning can begin on a regular basis. A tan normally appears after several exposures and is maximized after four (4) weeks of exposure in accordance with the recommended exposure schedule for your skin type. In order to maintain your tan, a maximum of two (2) weekly 12 minute sessions is recommended from the fth week onward. Do not tan more than once in a 24-hour period.

Part No: 1020362-00

19150 / 0

The sticker is mounted on the lamp cover foot end.








Not applicable for this device.

12.5.2 User settings overview

Not applicable for this device.



12.6.1 Navigation

During the tanning session, functions may be activated or deactivated via the control panel inside the device.

All of the pictograms displayed on the screen are illuminated in default mode after the device starts up.

The relevant pictogram will start to flash after a device function has been selected.



NOTE:

If no button is pressed within 8 seconds, the settings return to default mode.

			•	
	Function	Pictogram selectionl / Button sequence	/ Description / Display	Information
1.	Lamps		START/STOP Switches the lamps on / off during the tanning session	The tanning time continues to run if the lamps are switched off during tanning session.
2.	Face fan	►) -/+	Regulate the face fan, levels 1-9	The face cooling air nozzles can be adjusted manually.
4.	Facial tanner		Regulate the facial tanner, levels 1 - 3 Switch the facial tanner off: hold button down for 2 seconds Switch the facial tanner on	1 minute until up to maximum
				power
6.	Audio system (optional)	 → →	I.CH (internal): Music' SD-card Select title E.CH (external): externally connected system (e.g. CD player) Select channel MP3 player or smartphone	
7.	Voice Guide (optional)		Switch the Voice Guide off Switch the Voice Guide on	The Voice Guide provides acoustic device operating help and is only available if an audio system is fitted. Voice Guide is switched on as a standard item during stand-by and tanning.
8.	Volume (optional)		Volume control and switching off the audio systems	
9.	Air conditioning (optional)		Switch the air conditioning off: hold button down	

12.6.2 Description

12.7 Operating display of the sensor

Not applicable for this device.

12.8 Selection of the application

Not applicable for this device.

12.9 Sun Select setting with the outer interface

Not applicable for this device.

12.10 Measurement (automatic mode)

Not applicable for this device.

12.11 Connections

MP3 player and smartphone (optional)

WARNING!



Danger of hearing damage!

Using earphones or headphones at high volume can result in permanent hearing damage.

Do not set the volume too high.

A CAUTION! The heat might damage your MP3 player or smartphone! Do not place the unit directly in the radiation area. The cable might tear, the connectors might be damaged. _ Do not pull on the cable when unplugging the MP3 player or smartphone.

The user can connect their own private MP3 player or smartphone to the device.

- 1. Jack plug (JK Part # 4630911001-..) provided for use by the studio operator (2 x 3.5 mm stereo jack plug).
- MP3 player or smartphone connection: see the documentation from the 2. manufacturer of the MP3 player or smartphone.

Connecting:


- Insert the AUX cable (stereo jack plug) in the audio system. _
- Plug the AUX cable into the MP3 player or smartphone.
- Select the music title and then start.
- Where necessary, set the volume level on the MP3 player or smartphone so that the sound signal from the MP3 player or smartphone is recognized by the audio system.





NOTE:

The personal use of an MP3 player during tanning is not a public broadcast in copyright terms, so that there is no obligation for registration or payment by the studio owner to the corresponding copyright owning company. Copy right laws apply to the owner of the MP3 player.

The same regulations apply for the official use of MP3 music files as for other music sources: As studio owner you are only allowed to use original audio obtained from legal sources. Proof of the legitimacy of any MP3 audio used should be available for viewing upon demand of any regulatory body. Please refer to http://www.riaa.com for more information.







12.12 How to use



NOTE:

Before use the device must always be cleaned and disinfected! See chapter 12.15 How to clean/disinfect.

12.12.1 How to start

The device is started automatically with an internal or external timer.



NOTE:

See separate document 'Timer Control Module' #1008370-.. in the Technical Documentation folder.

Preparation time

Before the lamps turn on, you have a few minutes to prepare yourself. During the preparation time you can switch on the lamps at any time by pressing the START/STOP button.

- Remove your clothes and all jewelry.
- Remove make-up and other cosmetics.
- Remove glasses. Contact lenses can be worn under the protective goggles.
- Put on the protective goggles.
- Lie down on the bed surface.
- Close the canopy.
- Press the START/STOP button.

Settings on start-up:


- Low pressure lamps
- Facial tanners
- Body cooling
- Face cooling
- Audio system (optional)
- Voice Guide (optional)

12.12.2 Application tips

When describing the operation, the tanning device is often shown with the canopy open. During tanning the canopy must always be closed.

Proper operation is not possible with the canopy open.

 Lie down and place your head on the headrest or as indicated by the ergonomic base panel to maintain the proper distance between skin and lamps.



12.12.3 How to stop

The tanning session ends automatically after the preset time has run down. The internal body cooling fan continues to run for approx. three (3) minutes to sufficiently cool the device.

- To interrupt a tanning session, press and hold button START/STOP anytime during a session.
- Press START/STOP again to restart the lamps.

12.13 What to do after the treatment

12.13.1 Cleaning and disinfection

A WARNING!



Infections can be transferred through skin contact.

All items/equipment components, with which the user can come into contact during tanning, must be cleaned and disinfected after every tanning session:

- Protective goggles
- Acrylic panels
- Handles and control panel
- AUX cable
- Adjustable air nozzles
- Use only EPA registered quaternary ammonium germicidal based detergent solution (follow product label for use-dilution), such as Lucasol One Step, to clean and disinfect the tanning system and its components.



NOTE:

For thorough cleaning and disinfection, the product must be allowed to remain in contact with the surface being cleaned and disinfected for a specified amount of time.

This specified amount of time depends on the cleaner/ disinfectant which is used. Follow the directions for use of the cleaner/disinfectant.

After this specified application time remove remaining cleaner/disinfectant from the surfaces of the device. Use a singlepass paper towel.

12.14 Safety instructions for cleaning/disinfection and maintenance

A DANGER – HIGH VOLTAGE!



You can be killed or injured by an electric shock! During maintenance and service work there is a risk of touching live parts and receiving a fatal electric shock.

- The device must not be in use.
- Disconnect device from power supply before opening.
- Do not reach behind covers and do not open the device with the device switched on.
- Refit any safety devices (e.g. switches) after the work has been completed.

12428 / 0

If work is to be performed on the devices, they must be deenergized. That means that all live cables must be switched off.

Switching off the device alone is insufficient, as certain points may remain energized. Therefore, switch off fuses before performing any work and – if possible – remove them.

Accidental reactivation can result in serious accidents. Immediately after deenergizing, secure all switches or fuses used for deenergizing against being switched on again.

- Lock the fuse box with a padlock.

In case of circuit breakers which cannot be unscrewed, a strip of adhesive tape may be applied over the actuation lever (1 + 2) with the wording 'Do not switch, danger!'.

A prohibition sign with the text:

'Work in progress!'

'Place:

'Sign may only be removed by:'

must always be securely mounted immediately.

It is imperative that you, the owner and/or operator, check all components for any signs of wear which may occur through normal use.

- Observe the cleaning/disinfection and maintenance schedule specified in the tables in Chapter 12.15.2 and 12.16.2.
- Only replace low-pressure lamps with the original type or compatible lamps.

Should you require any assistance or need additional information, please call Global Service USA at 800 445 0624, Monday through Friday 8:00 a.m. - 5:00 p.m. CT.



NOTE:

The service of the device may only be carried out by a (Level 2) JK Factory Certified Technician.



WARNING!

A WARNING!

Injuries and damage due to improper maintenance!

If the maintenance intervals for the UV lamps are exceeded or incompatible UV lamps are installed, the share of harmful UV radiation may increase. Sunburn and other skin damage may result.

Improper maintenance can cause the device to be damaged or to become unusable.

- Always comply with the specified maintenance intervals, see chapter 12.16.2 Maintenance plan.
- Follow the cleaning/disinfection instructions.

Danger of burns from hot lamps and device parts!

If the tanning device was operated before being switched off and opened, lamps and housing parts may be hot.

 Before replacing lamps or other spare parts, wait until lamps and metal parts of the device have cooled down sufficiently.

Danger of squeezing!

When opening and closing the panels and acrylics, you can squeeze your fingers.

Maintenance and care play a major role in deciding the devices performance and appearance over its useful life. Diligent compliance at the specified intervals is absolutely necessary to ensure the proper operation of your device.

The current operating hours of the parts requiring maintenance can be displayed in the Presetting mode – see separate instructions 'Presettings' #1011803-.. in the Technical Documentation folder.

Please note that the device must be inspected regularly by a JK authorized representative every 12 months (from date of installation) to maintain its proper condition!

Acrylic panel

NOTICE

Cosmetics may cause cracks to form on the surface!

Over the long-term cosmetics or sunscreens cause damage (e.g. crack formation on the surface).

- Ensure that cosmetics and sunscreens are removed before tanning.

The acrylic panels for the tanning devices are produced of acrylic glass developed especially for this application. The acrylics used feature a particularly high UV permeability and resistance, as well as an easy-care, hygienic surface that is gentle on the skin.

The acrylic panels are formed to device-specific shapes in a technically complex production process. Despite state-of-the-art production know-how, the presence of minor spots, air bubbles or streaks in the acrylic panels is unavoidable. In addition, hairline cracks can occur on the acrylic panel during operation.

These occurrences are material-related and are unavoidable in processing. However, they have no significant effect on use and are therefore not accepted as defects.

Over the course of time the acrylic panel will become discolored as a result of usage and must be replaced by customer-service personnel on a regular basis.

The optional partition (only for devices with an air conditioning unit) works as a UV filter and must be replaced by customer-service personnel on a regular basis.

12.15 How to clean/disinfect

A WARNING!



Infections can be transferred through skin contact.

All items/equipment components, with which the user can come into contact during tanning, must be cleaned and disinfected after every tanning session:

- Protective goggles
 - Acrylic panels
 - Handles and control panel
 - AUX cable
 - Adjustable air nozzles
 - Use only EPA registered quaternary ammonium germicidal based detergent solution (follow product label for use-dilution), such as Lucasol One Step, to clean and disinfect the tanning system and its components.



NOTE:

For thorough cleaning and disinfection, the product must be allowed to remain in contact with the surface being cleaned and disinfected for a specified amount of time.

This specified amount of time depends on the cleaner/ disinfectant which is used. Follow the directions for use of the cleaner/disinfectant.

After this specified application time remove remaining cleaner/disinfectant from the surfaces of the device. Use a singlepass paper towel.

12.15.1 Cleaning and disinfection of surfaces

Acrylic panel

NOTICE

Do not rub with a dry cloth – danger of scratching!

 Other cleaning agents, especially concentrated disinfectants or solvents (e.g. Lysoform, ethyl alcohol or other liquids containing alcohol) must never be used for cleaning. Failure to observe this voids all warranty claims.

Acrylic panels (3) & (7) referenced in section 12.15.2 'Cleaning/disinfection plan'

These panels are not in direct contact with the user, however they can become soiled if the user inadvertently touches them. If these panels are left soiled for an extended period of time, the heat and light from the tanning lamps may cause the soiled areas to become permanently stained. Therefore we recommend frequently inspecting and cleaning these panels when necessary, to ensure the serviceable life of the acrylic.

- Remove fingerprints and other soiling carefully.

Plastic surfaces



For cleaning the remaining painted and unpainted plastic surfaces, it is best to simply use warm water and commercially available soft chamois leather. Never use aggressive cleaning agents containing alcohol or essential oils. These may lead, in the long run, to damages not covered by the warranty.


During cleaning a slight discoloration of the leather cloth by the rubber seals should be expected for production-related reasons.

Prevent damage to the acrylic glass and plastic surfaces.

– Remove rings, watches, bracelets etc. before starting cleaning work.

Filter panels and lamps

- Low pressure lamps and filter panels can be cleaned with a damp cloth (without additional cleaning agents) where necessary.
- UV high pressure lamps can be cleaned with ethyl alcohol where necessary.





NOTE:

If desired, you may set the unit to require that cleaning/disinfection be confirmed after each tanning session by pressing the START/STOP button (when the cool-down time for the main fan has finished).

12.16 How to maintain

12.16.1 Technical modifications

The device has been constructed in accordance with current safety regulations. The illustrations and specifications on these instructions are subject to technical modifications which are required in order to improve the device.

Unauthorized modifications and changes to the device and its control unit are prohibited.

Use only OEM spare parts.

12.16.2 Maintenance plan



NOTE:

The service of the device may only be carried out by a (Level 2) JK Factory Certified Technician.

NOTICE


Only use OEM spare parts of the same type! The use of other parts will void the manufacturer's warranty!

Any liability is excluded in case of damage or injury proven to be the result of the use of non-genuine spare parts.

The following maintenance activities shall be performed by the studio operator or a (Level 1) JK Factory Certified Technician.

The following items are considered consumables and should be replaced as noted. Replacement of these components helps ensure continued performance of the device.

Maintenance performed by the studio operator or a JK Factory Certified Technician



	Component	Interval					Activity	See page
		500 operating hours	750 operating hours	800 operating hours	1000 operating hours	3000 operating hours		
1	Facial tanner, UV high pressure lamps		Х				Replace	73
1	Facial tanner, low pressure lamps	Х					Replace	73
1	Starter, canopy (facial tanner UV low pressure lamps)				Х		Replace	73
8	Partition					Х	Replace	72
2	Low pressure lamps, base			Х			Replace	72
3	Low pressure lamps, canopy			Х			Replace	73
10	Starter, interior lighting						Inspect and replace as necessary	73
5	Starter*, accent light, canopy						Inspect and replace as necessary	73
6	Starter, accent light, front panel						Inspect and replace as necessary	75
1	Facial tanner filter panels					Х	Visual control	71
9	Filter mat					Х	Replace	76
7	Filters					Х	Replace	75
11, 12	Filters					Х	Replace	77
13	Filter mat					Х	Replace	77

 $^{\ast}\mbox{Contact}$ the customer service if the accent lighting in the canopy fails.

Maintenance performed by authorized, trained and qualified staff

WARNING!



Danger to persons from maintenance work that has not been carried out!

If maintenance work is not carried out, it can lead to material damage or personal injuries!

- Maintenance work may only be carried out by personnel who have been authorized, trained and qualified by JK Products & Services, Inc.!
- The studio operator is responsible for compliance with the maintenance intervals!

The maintenance work must be carried out in accordance with checklist 1018814-.. by a JK Factory Certified Technician at the manufacturer or by personnel who have been authorized, trained and qualified by the manufacturer.

The correctly carried out maintenance work must be entered and confirmed in checklist 1018814-...

The maintenance work must be carried out at the following intervals:

- Every 1500 operating hours
- Annually or every 2000 operating hours, whichever is sooner.
- After 5000 operating hours
- After 10 years or 20,000 operating hours, whichever is sooner.

Once the age of the device reaches ten (10) years from the date of manufacture, its condition must be assessed by a (level 4) JK Factory Certified Technician before use of the device can be continued.


Failure to have this device assessment performed may result in personal injury or property damage.

Any liability is excluded if use of the device continues ten (10) years after the date of manufacture, without the "condition assessment" having been performed.

12.16.3 Cleaning and maintenance work preparation

Service kit


- 1. Allen key
- 2. Suction cup for filter panels, acrylic panel and canopy panel
- 3. Scratch prevention for the entry area (support cushion for the canopy)



1019103-00

2

 \mathcal{D}




The service kit is fitted on the inside of the front panel.

- Opening the bed base: see page 67.


– Remove service

13334 / 0

Remove service kit from support.



- Use the cushion as scratch prevention when opening the canopy panel.




Lift up the acrylic panel and remove the partition

- Lift up the acrylic panel.
- Lift up the supports and prop the acrylic panel on them.

NOTICE


Risk of scratching!

- Use the recesses provided on the acrylic panel.




- Remove the lamp covers at the head and foot ends.

- Raise the partition with the suction cup.




- Remove the partition.



The assembly is the same process in reverse order.


When assembling the device please note:

- Clean the partition.
- Hold the partition with a cloth in order to prevent finger prints.




Remove the canopy panel

- Turn the locks through 90°: first the outer locks, then the lock in the middle.
- Support the canopy panel with one hand so that it does not fall down.




- Carefully lower the canopy panel.




The canopy panel must be completely removed from the device in order to replace the lower, long low pressure lamps.

- Undo the cable tie and unplug the connector.




- Remove the canopy panel with the aid of a helper.



When assembling the device please note:


- Carefully lay the canopy panel in the guide.




NOTICE!

The cable may get damaged!

– Do not pinch or kink the cable.




- Support the canopy panel with one hand so that it does not fall down.
- Re-lock the locks: first the lock in the middle, then the outer locks.
- Remove fingerprints and other soiling carefully.



Open the bed base

- Raise the acrylic panel and grasp the recessed grip.
- Lift up the bed base.



The assembly is the same process in reverse order.




WARNING!
Crushing hazard when closing the bed base!

Fingers can be jammed.

Do not hold fingers between bed base and front panel.

12.16.4 Instructions for replacing the lamps



The UV effect of the lamps and thus the tanning effect decreases over the course of time. Therefore, the replacement intervals specified in the maintenance plan must be adhered to.

UV filters are utilized in order to control the UV radiation, e.g. the filter panels on the facial tanner. However, the filter effect decreases over the course of time. Therefore, the replacement intervals specified in the maintenance plan must be adhered to.



NOTE:

Small quantities of mercury can escape if the bulb/lamp glass breaks! Please comply with the following instructions:

- Immediately disconnect the device from the mains power.
- Children must leave the room immediately.
- Ventilate the room for at least 15 minutes.
- Put on disposable gloves.
- With the window open: Collect the glass shards and escaped mercury in a sealable container.
- Take the container to a collection site for waste lamps.

Changing the chip card

Not applicable for this device.

Low pressure lamps

WARNING!




Danger of burns from hot lamps and device parts!


If the tanning device was operated before being switched off and opened, lamps and housing parts may be hot.

WARNING!


 Before replacing lamps or other spare parts, wait until lamps and metal parts of the device have cooled down sufficiently.

- Replace faulty low pressure lamps immediately.
 - Always replace the entire set of lamps after the specified operating time.
- Turn 90° and carefully remove from the socket.







 Low pressure lamps possess a reflector which directs the light outwards. The lamps must be mounted in such a way that the rear side of the reflector is located on the device side.



- Push the pins vertically into the socket from above.




Turn the lamp 90°.
 The lettering must be oriented towards the outside (i.e. towards the tanning room or towards the user).




Makrolon tubes

Coloured makrolon tubes can be fitted on the accent lamps. The makrolon tubes do not have to be changed, merely refitted with the new lamps.

- Remove the makrolon tube from the old lamp.



- Slide the makrolon tube onto the new lamp.



Starter


• Replace faulty starters immediately.

You can recognize a faulty starter by the blackened ends of the lamps or when the lamps can no longer be started.

Operating a lamp with a faulty starter significantly shortens its service life. The lamp loses power and may begin to flicker under certain circumstances.

The starters are located in either one of the two lamp sockets or are visible when the lamps are removed.

- Turn 90° and carefully remove from the socket.



High pressure lamps and filter panels

WARNING!

Danger of burns from hot lamps and device parts!

If the tanning device was operated before being switched off and opened, lamps and housing parts may be hot.

 Before replacing lamps or other spare parts, wait until lamps and metal parts of the device have cooled down sufficiently.

Fire hazard due to overheated lamps!

Non-approved high pressure lamps can explode. Hot lamp components can set other parts on fire. People can be killed or severely injured due to smoke inhalation and fire.

- Only fit the high pressure lamps specified by the manufacturer.
- Clean the inside of the device regularly. Dust particles are flammable!
- Release the clamping holder.

WARNING!


- Lift the filter panel, pull it out of the guide and remove it.



2


13348 / 0


- Unplug the UV lamps.
- Clean the reflector.



- Only utilize original UV lamps.







- Only touch new lamps in the handling zone.

- Test the safety switch to ensure that it works.
 The safety switch ensures that the device switches off in the event of a faulty filter panel or when a filter panel is missing.
- Press the button and release it.
 If the button springs back automatically then it is functional.
 Replace the filter panel.


12.16.5 Cleaning and disinfection of the sensor

Not applicable for this device.


12.16.6 Cleaning or replacing lamps in the base


 Lift up the acrylic panel and then remove the lamp covers and the partition: see page 64.

Replacing lamps: see page 69.



 Please maintain the correct order of the Genesis Type R HYBRID Performance low pressure lamps and Genesis Type U HYBRID Performance UV low pressure lamps.
 a1: Genesis Type R HYBRID Performance low pressure lamps a2: Genesis Type U HYBRID Performance UV low pressure lamps





The assembly is the same process in reverse order.

When assembling the device please note:

- Clean the partition.
- Hold the partition with a cloth in order to prevent finger prints.

12.16.7 Cleaning or replacing the lamps in the side section


Not applicable for this device.

12.16.8 Cleaning or replacing lamps in the canopy


- Removing the canopy panel: see page 65.

The following components listed in the maintenance plan are fitted in the canopy:

- UV low pressure lamps (1.80 m): see page 69.
- Low pressure lamps (1.80 m): see page 69.
- Facial tanner UV low pressure lamps and the associated starters: see page 69.
- Facial tanner UV high pressure lamps: see page 71.
- Facial tanner filter panels: see page 71.





- Please maintain the correct order of the Genesis Type R HYBRID Performance low pressure lamps and Genesis Type U HYBRID Performance UV low pressure lamps.
 - a1: Genesis Type R HYBRID Performance low pressure lamps
 - a2: Genesis Type U HYBRID Performance UV low pressure lamps



The facial tanner's low pressure lamps must be removed first so that the UV high pressure lamps and the filter panels can be changed.

- Remove the lamps.





 Remove the two upper low pressure lamps in the canopy so that you can then access the facial tanner's low pressure lamp starter.

Replacing lamps: see page 69.

Replacing starters: see page 70.

UV high pressure lamps and filter panels: see page 71.

When assembling the device please note:


- Support the canopy panel with one hand so that it does not fall down.
- Re-lock the locks: first the lock in the middle, then the outer locks.
- Remove fingerprints and other soiling carefully.

12.16.9 Cleaning or replacing the lamps and filter panels in the shoulder tanner

Not applicable for this device.

12.16.10 Cleaning or replacing the interior lights

- Removing the canopy panel: see page 65.




7

8

1D


13270/0

- Remove the 2 lamps above and the 2 lamps below the interior lighting.



Remove the cover.

Replacing lamps: see page 69. Replacing starters: see page 70.



The assembly is the same process in reverse order.

12.16.11 Cleaning or replacing the canopy accent lighting

* Contact the customer service if the accent lighting in the canopy fails.

12.16.12 Cleaning or replacing the front panel accent lighting


- Opening the bed base: see page 67.
- From the front reach into the front panel and remove the accent light.

Replacing lamps: see page 69.

Replacing starters: see page 70.

Makrolon tubes: see page 70.

The assembly is the same process in reverse order.




12.16.13 Cleaning the filters in the base

- Opening the bed base: see page 67.


1

17936 / 0



Remove the filters.

Clean the filters wet or dry.
 Dry cleaning: Vacuum cleaner (depending on the degree of soiling)
 Wet cleaning: Use water and detergent or put in a dish-washer




NOTICE!

The device may be damaged by moisture! The cleaned filters must be dry before they are replaced.


- Reinstall the cleaned and dried filters.

The assembly is the same process in reverse order.



12.16.14 Cleaning the filter mat in the canopy


- If necessary, cover the canopy in order to prevent the paint from being scratched.
- Remove the filter mat fitted at the back of the canopy.



- Dry or moist clean the filter mat or replace with new ones.

Dry cleaning: Vacuum cleaner (depending on the degree of soiling) Moist cleaning: Water and detergent

– Do not clean in the dish-washer!



NOTICE!

The device may be damaged by moisture! The cleaned filter must be dry before they are replaced.

- Reinstall the cleaned and dried filter mat.

12.16.15 Cleaning the filter mats in shoulder tanner

Not applicable for this device.

12.16.16 Air conditioning (optional): Empty the condensation tank and clean the filter


NOTICE

Damage to the device through soiled filters and cooling fins!


Regularly check the filter grill and cooling fins on the air conditioning system and clean if necessary.

We recommend using the specially manufactured fin comb, art-no. 15720470, to clean the cooling fins.


- Opening the bed base: see page 67.




- Bring the condensation tank forwards.
- Disconnect the hose on the condensation tank.
- Empty the condensation tank.



Remove the cover.




- Remove the filter from the holder.




- Clean the filter moist or dry:

Dry cleaning: Vacuum cleaner (depending on the degree of soiling) Moist cleaning: Water and detergent


– Do not clean in the dish-washer!




- Remove the filter from the holder.



Clean the filters wet or dry.
 Dry cleaning: Vacuum cleaner (depending on the degree of soiling)
 Wet cleaning: Use water and detergent or put in a dish-washer




Use a fin comb to clean the air conditioning's dirty cooling fins.




NOTICE!


The device may be damaged by moisture! The cleaned filters must be dry before they are replaced.

- Reinstall the cleaned and dried filters.
- Ensure that the filters are correctly positioned in the holder.





- Attach the cover.



- Connect the condensation tank to the hose.
- Replace the condensation tank.
- Close the bed base.

12.16.17 AQUA / AROMA SYSTEM maintenance

Not applicable for this device.

12.17 How to store the device

12.17.1 Decommissioning

The device must be disconnected from the power supply in order to temporarily or permanently decommission it.

You must abide by the legal disposal requirements when permanently decommissioning the device.

12.17.2 Storage

Store the devices in a dry location with a stable temperature. Once the device has cooled off, pack it in plastic wrapping to protect it against scratches.


- Storage temperature: between 5 °F (-15 °C) and 140 °F (+60 °C)
- Air pressure: between 794 hPa and 1060 hPa
- Relative humidity: between 30 % and 70 %


12.17.3 Disposal

Environmental regulations – disposal of lamps and batteries

Lamps contain fluorescent materials and other waste containing mercury. Batteries contain heavy metal compounds.

Dispose of lamps and batteries according to the national waste disposal laws and in accordance with the municipal waste regulations.





Packaging

All packaging consists of 100 % recyclable materials.

Disposal of old devices

The device has been manufactured using recyclable materials. The JK Corporate Group will provide you with information on the content or potential hazards of the materials used.

Disposal of consumable supplies

Dispose of consumable supplies and their contents according to the national waste disposal laws and in accordance with the municipal waste regulations.

13 What to do when things go wrong



WARNING!

Failure to use protective eyewear may result in severe burns or other eye injury. If discomfort develops, discontinue use and consult a physician.

- A person who does not tan in the sun most likely will not tan from the use of this device. Persons with very sensitive skins (skin type I) must not use the unit, as with this skin type tanning is impossible without damaging the skin (e.g. sunburn).
- Individuals with acute sunburn, individuals who have had or have skin cancer, or individuals who are at increased risk of skin cancer, must not use the system.
- UV devices must not be used without taking medical advice if unexpected effects, such as itching, occur within 48 hours of the first session.
- The tanning device must never be used if the timer is defective!
- UV light from the sun or UV systems can cause injuries to the skin or eyes. This biological effect is dependent on the sensitivity of the individual's skin and on the type and amount of UV light.
- As with natural sunlight, overexposure can cause eye and skin injury, sunburn, and allergic reactions.
- Repeated exposure may cause premature aging of the skin and skin cancer.
- Medications (taken internally or otherwise) or cosmetics applied to the skin, may increase sensitivity to ultraviolet light.
- A person having a history of skin problems should consult a physician before use.
- Seek medical advice if in doubt!



NOTE:

Occasionally, persons using the tanning device will experience a slight reddening of the skin – usually in small patches – after the second or third session. This redness is often accompanied by an itching sensation. This may be nothing more than a very limited heat 'rash' caused by heat from the lamps within the device. It should go away within approximately 24 hours and should not reappear. This rashing can be lessened or prevented by applying moisturizer lotion to the affected area after the tanning session is completed.

- Follow instructions.
- Increasing tanning also requires an extension of the exposure time (= radiation time) or after a certain degree of tanning has been achieved, a further intensification is not possible. However, the radiation time may not be extended as desired within the scope of the permissible radiation doses! Therefore, only a certain degree of final tanning dependent on the skin type can be achieved without endangering your health.
- Inform users about proper tanning.

13.1 Troubleshooting

Software and device malfunctions are indicated by error codes, e.g. E005.

These error codes are output to the display to simplify troubleshooting:

- If a fault occurs, the error code flashes on the display.
- If several errors occur, the error messages are displayed alternately.
- Error elimination is acknowledged by pressing the START/STOP button.
- If the error cannot be cleared, contact Customer Service (see page 2) or your local service provider

More detailed information regarding the error description and solutions is available in the document 'Error codes' #1011831-.., which you find in the Technical Documentation folder.

For authorized, trained and qualified staff:

For further technical description, please contact Customer Service (see page 2).

Danger of skin injuries and skin diseases.



The tanning device must never be used if a filter panel is missing or damaged, or the timer is defective!

14 Where you can find out more

If you have any questions, please contact Customer Service (see page 2).

15 How we studied this device

The system is built to the state of the art and the applicable safety regulations.

We reserve the right to make technical changes which are necessary to improve the system or a system component even if they deviate from pictures and information in these instructions.

16 Appendix

16.1 JK 126 / 42-4 HT & JK 126 / 42-4 HT AC: EMC information

16.1.1 Table 201: Guidelines and manufacturer's declaration – Electromagnetic emissions

The tanning system has been designed for use in the electromagnetic environment specified below. The device operator must ensure that it is used in such an environment.

Emission measurements	Conformity	Electromagnetic environment – Guidelines
HF emissions as per CISPR 11	Group 1	JK 126 / 42-4 HT & JK 126 / 42-4 HT AC uses HF pow- er mostly for internal functions. Therefore the HF emis- sions are very low and it is highly unlikely that it will cause any interference to adjacent electronic equip- ment.
HF emissions as per CISPR 11	Class B	JK 126 / 42-4 HT & JK 126 / 42-4 HT AC has been de- signed for use in all devices, including those in residen- tial areas, and it has been determined that it can be used for residential purposes as soon as it is connected up to a public mains supply that also supplies buildings.
Harmonics IEC 61000-3-2	Class A	
Voltage fluctuations / Flicker IEC 61000-3-11	Fulfilled	The obligations listed in Sub-section 6.2.2 of EN 61000- 3-11:2000 must be taken into consideration. In particu- lar, the 0.14 ohm line impedance must be guaranteed.

16.1.2 Table 202: Guidelines and manufacturer's declaration – Electromagnetic interference

The tanning system has been designed for use in the electromagnetic environment specified below. The device operator must ensure that it is used in such an environment.

Interference immunity tests	IEC 60601 - Test level	Defined level	Electromagnetic environment – Guidelines
Discharging static electricity (ESD) IEC 61000-4-2	±6 kV contact discharge ±8 kV air discharge	±6 kV contact discharge ±8 kV air discharge	-
Fast transient electrical noise / bursts IEC 61000-4-4	$\pm 2 \text{ kV}$ for mains supplies	$\pm 2 \mbox{ kV}$ for mains supplies	-
Surges 61000-4-5	±1 kV series mode voltage ±2 kV common mode voltage	±1 kV series mode voltage ±2 kV common mode voltage	-
Magnetic field radiated by supply frequency (50/60 Hz) IEC 61000-4-8	3 A/m	3 A/m	-
Voltage drops, Short interruptions and supply voltage fluctuations IEC 61000-4-11	<5% U _T (>95% drop in U _T) for 0.5 periods 40% U _T (60% drop in U _T) for 5 periods 70% U _T (30% drop in U _T) for 25 periods <5% U _T (>95% drop in U _T) for 5 s	<5% U _T (>95% drop in U _T) for 0.5 periods 40% U _T (60% drop in U _T) for 5 periods 70% U _T (30% drop in U _T) for 25 periods <5% U _T (>95% drop in U _T) for 5 s	-

Note: U_T is the mains alternating voltage used for the test levels.

16.1.3 Table 204: Guidelines and manufacturer's declaration – Electromagnetic interference

The tanning system has been designed for use in the electromagnetic environment specified below. The device operator must ensure that it is used in such an environment.

Interference immunity tests	IEC 60601 - Test level	Defined level	Electromagnetic environment – Guidelines
			Portable and mobile radios are not to be used at shorter distances to the JK 126 / 42-4 HT & JK 126 / 42-4 HT AC and its cables other than the recommended safe distance, which has been calcu- lated according to the transmitting frequency are made.
			Recommended safe distance:
			$d = 1.2\sqrt{P}$
Conducted	3 Vrms	3 Vrms	$d = 1.2\sqrt{P}$ 80 MHz to 800 MHz
HF noise IEC 61000-4-6	150 kHz to 80 MHz		$d = 2.3\sqrt{P}$ 800 MHz to 2,5 GHz
Radiated HF noise IEC 61000-4-3	3 V/m 80 MHz to 2,5 GHz	3 V/m	P is the transmitter's maximum output power (nomi- nal rating) in Watts (W) according to the details pro- vided by the manufacturer of the transmitter and the recommend safe distance is given in metres (m).
			The field strength of the stationary radio transmitter is for all frequencies ^b in accordance with tests that were carried out onsite ^a less than the determined level.
			Interference is possible in the immediate surrounding of equipment that carry the following symbols.
			$\begin{pmatrix} ((\bullet) \end{pmatrix} \end{pmatrix}$

Comment 1: The higher value applies to 80 MHz und 800 MHz.

Comment 2: These guidelines might not apply to all situations. The propagation of electromagnetic waves is affected by absorption and reflexes caused by buildings, objects and people.

- a The field strength of a stationary transmitter e.g. standard cell phone stations (mobile / cordless phones) and public mobile radio services, amateur stations, MW and UHF radio and TV transmitters) cannot be precisely determined for theoretical reasons. It is recommended that an onsite test should be carried out in order to determine the electromagnetic environment caused by stationary HF transmitters. If the field strength of the massage device determined at the installation site exceeds the defined HF level listed above then the device must be monitored with regard to its normal operation. If any abnormal characteristics are recorded then it will be necessary to introduce additional measures, such as reorientation or converting the device.
- b The field strength must be less than 3 V/m over the frequency ranges from 150 kHz to 80 MHz.

16.1.4 Table 206: Recommended safe distances between portable and mobile HF communications equipment and JK 126 / 42-4 HT & JK 126 / 42-4 HT AC

JK 126 / 42-4 HT & JK 126 / 42-4 HT AC has been designed for use in an electromagnetic environment in which the radiated HF interference is controlled. The operator of the device can help to reduce electromagnetic interference by maintaining a safe distance between the portable and mobile HF communication devices (transmitters) and the device itself as recommended below with regard to the communication device's maximum output power.

Nominal transmitter power (W)	Safe distance with regard to the transmitting frequency (m)		
	150 kHz to 80 MHz $d = 1.2\sqrt{P}$	80 MHz to 800 MHz d = 1.2√P	800 MHz to 2.5 GHz $d = 2.3\sqrt{P}$
0,01	0,12	0,12	0,23
10	3,8	3,8	7,3
1	1,2	1,2	2,3
0,1	0,38	0,38	0,73
100	12	12	23

The recommended safe distance (d) in metres (m) can be determined by using the equation that applies to the transmitters frequency in the case of transmitters where their nominal power is not listed above, whereby 'P' is the nominal transmitter power in Watts (W) according to the details supplied by the manufacturer of the transmitter.

Comment 1: The higher value applies to 80 MHz und 800 MHz.

Comment 2: The propagation of electromagnetic waves is affected by absorption and reflexes caused by buildings, objects and people.

17 JK-Products, Inc. – Limited Warranty

JK-Products, Inc. warrants its products to be free from defects in materials and workmanship under intended normal use as described in the unit's Operation and Instruction Manual, for a period of three (3) years from date of sale.

This Limited Warranty applies only to the original purchaser of the equipment through JK-Products, Inc. or its authorized dealer or distributor, and is not transferable.

Global Service USA obligations under this warranty are limited to repair or replacement of any defective part without charge for that part to the original purchaser, with the following exceptions:

A Fluorescent lamps are warranted against defects for a period of thirty (30) days from date of sale.

B Only parts obtained through JK-Products, Inc., its authorized dealers or distributors may be used. Transportation costs for parts shipped to the consumer and the return of defective parts to Global Service USA are not included.

C Labor will be furnished without charge for ninety (90) days from date of purchase only. All labor and related charges must be authorized by Global Service USA prior to start of repairs, and must coincide with Global Service USA established rates and time allotment policy.

D Acrylic: Refer to Manufacturer's Acrylic Warranty Policy. It is imperative that the original customer completes and returns the enclosed warranty card within 10 days after purchase to insure valid registration and coverage for potential claims.

E Items considered to be wear items such as rubber foot mats, buttons, or other items which the user comes into contact with during normal operation of the device, are warranted for a period of 30 days from the date of purchase.

If the warranty card is not registered, proof of purchase from JK-Products, Inc. or its authorized dealer or distributor will be required prior to any consideration on warranty claims. This could result in service delays.

This warranty is extended to the individual or legal entity, whose name appears on the warranty registration card filed with Global Service USA, or whose name appears on the original sale document and may not be transferred to any other individual or legal entity.

This warranty does not apply to any failure of the product, or any parts of the product due to alterations, modifications, misuse, abuse, accident, improper maintenance, improper installation, acts of God or if the serial number on the product has been removed, altered or defaced. Adequate packaging must be used for returned goods to prevent freight damage.

There are no warranties which extend beyond the description on the face hereof. There is no express or implied warranty of fitness of merchantability.

The remedies provided in this limited warranty are the exclusive remedies provided to the purchaser by Global Service USA and are provided in substitution of all other remedies. Consequential and incidental damages are excluded.

No person, firm or corporation is authorized to obligate JK-Products, Inc. for any liability in connection with the sale or use of these goods.

17.1 Limited Acrylic Warranty

JK Products, Inc. warrants its acrylic sheets to be free from defects in material and workmanship, under intended normal use, for a period of one (1) year from date of sale of the tanning bed or 1,200 hours of operation whichever comes first. Due to the tanning lotions, cosmetics, disinfectant and improper cleaners used on tanning surfaces that cannot be controlled by JK Products, Inc., after the first thirty (30) days of warranty period acrylic will be subject to a prorated cost to the consumer.

JK Products, Inc. obligations do not include transportation charges on replacement acrylic.

JK Products, Inc. assumes no liability for the cost of removing defective sheets or installing replacement sheets, or for damage to persons or property.

To make a claim, contact an authorized dealer or distributor of JK-Products, Inc. or Global Service USA with the model number, the serial number, and the date of purchase of the bed in which the acrylic will be used.

There are no warranties which extend beyond the description on the face hereof. There is no express or implied warranty of fitness or merchantability.

The remedies provided in this limited warranty are the exclusive remedies provided to the purchaser by Global Service USA and are provided in substitution of all other remedies. Consequential and incidental damages are excluded.

JK Products & Services, Inc. 411 West Washington Avenue Suite B Jonesboro, Arkansas 72401 Phone: 800-445-0624 Fax: 870-935-9046 E-mail: support@jkamerica.com http://support.jkamerica.com

17.2 Warranty Claims

17.2.1 Policy & Procedures

1. When to file a Warranty Claim:

In the event that your tanning system is not functioning properly under intended normal use as described in the unit's Operation and Instruction Manual, you may then have established cause to file a Warranty Claim.



NOTE:

Both the tanning system and legal registered owner must meet the criteria established under JK Products, Inc. Limited Warranty as described in this manual before any Warranty Claim will be considered.

2. Where to call to place a Warranty Claim:

JK-Products, Inc. is supported nationwide by an extensive dealer/distributor network through whom the majority of our units are sold. These dealers/distributors are required by contract to stock sufficient parts to meet the various warranty and nonwarranty needs of their customers.

Therefore, in order for you to properly file a Warranty Claim, you must locate the name and phone number of the dealer/distributor through whom you purchased your unit. Normally this information can be easily located either on your paid invoice or other proof of purchase documentation that you received when taking delivery of the unit.

Next, notify the dealer/distributor of the serial number, model number and date unit was purchased. This will initiate the Warranty Claim process.

Upon determination of the problem, your dealer/distributor can then supply you with the part(s) and proper instructions to return your unit to working order.

Each dealer/distributor has their own internal procedure for handling Warranty Claims and credits.



NOTE:

JK-Products, Inc., the manufacturer, does not involve itself in the direct handling of a Warranty Claim except where mitigating circumstances apply and where required by law.



NOTE:

If a part returned to Global Service USA proves to be operational and not defective, or if product code numbers on part do not correspond with individual unit date on file with Global Service USA, then a 30% restocking fee will be charged in addition to the retail purchase price of part.

Acknowledgment of the Agreement is not required for acceptance of the foregoing stipulations. You must comply to the instructions and warnings under chapter:

- 4.1 Intended use
- 5.1 Prohibited usage
- 6.1 What you must do to avoid serious harm

Any other use shall be considered improper. The manufacturer cannot be held liable for damage or injuries resulting from misuse. The operator bears the sole risk for this.

The proper use also includes compliance with the manufacturer's instructions, operating and maintenance conditions. This device may only be operated, maintained and repaired by persons familiar with these tasks and who are aware of the dangers involved.

17.2.2 Labor Warranty Claim/Credit Procedures

Global Service USA furnishes labor without charge for a period of 90 days from date of purchase. All labor and related charges must be authorized by Global Service USA prior to start of repairs, and must coincide with Global Service USA established rates and time allotment policy.

Please contact our Service Department for authorization and billing procedures.

17.3 Limited Lifetime Warranty

Global Service USA warrants specific individual components of the tanning system against defects in materials and workmanship for the life of the product. Coverage is limited to units purchased after November 1, 1994.

This warranty is restricted to the following components only:

- Steel Back Panels
- Structural Steel Frame Components
- Exterior Steel Body.



NOTE:

Components are warranted on an individual basis and not as they may effect the complete product.

Warranty coverage does not include cosmetic abnormalities such as scratches, nicks, dents, rust, oxidation of paint or other cosmetic changes that do not interfere with the designed function of the unit.

This warranty does not include failure of the product due to alteration, modifications, misuse, abuse, improper maintenance, improper installation or repair.

This warranty is not transferable and is only applicable to the original purchaser named on a completed and registered warranty record at JK-Products, Inc. headquarters.

JK Products, Inc. obligations do not include transportation charged on the shipping of new components to the customer or on the return of defective components of the manufacturer. All freight charges must be paid by the customer.

There are no warranties which extend beyond the description on the face hereof. There is no express or implied warranty of fitness or merchantability.

The remedies provided in this limited warranty are the exclusive remedies provided to the purchaser by Global Service USA and are provided in substitution of all other remedies. Consequential and incidental damages are excluded.



NOTE:

Any misuse, abuse, modification, alteration, improper maintenance, improper installation, etc. of this product or its intended use will subject said party to direct responsibility and liabilities for any and all consequences resulting from such action. Furthermore, such actions will void all warranties and may relieve Global Service USA of any liabilities relating to said product.



II. 111.

Limited Warranty

JK Products and Services warranties it products to be free from defects in materials and workmanship under intended normal use as described in the Operation/Instruction Manual. Refer to the Operation/Instruction Manual for specific details

This Limited Warranty applies only to the original purchaser of the equipment through JK Products and Services or its authorized distributors or dealers and may not be transferred.

 JK Products & Services' obligations under this warranty are limited to the repair (or replacement) of the defective part without charge to the original purchaser with the following exceptions:

 I.
 Lamps (fluorescent or high pressure) are warranted against defects for a period of thirty (30) days from the date of sale.

 II.
 Only parts obtained through JK Products & Services, its authorized distributors or dealers may be used.

 III.
 Replacement parts provided may be either new or reconditioned at the discretion of JK Products & Services.

 IV.
 Transportation cost for parts shipped to the customer and the return of defective parts are not included.

 V.
 Returned parts must be received in a condition such that its functional status at the time of its removal may be ascertained. Adequate packing must be used when returning any part to JK Products & Services. Warranty coverage may be denied for any claim where the part is damaged as a result of poor or inadequate packing must be used when returning any part to JK Products & Services.

Tertaining any part to the Product's Services. Warranty Owerage may be deneed for any damin where the part is damaged as a result of pool of inadequate packaging. Labor will be furnished without charge for a period of ninety (90) days from the date of sale to the original purchaser at the original location of installation. All labor related charges must be authorized by JK Products & Services prior to repair and performed by a technician authorized by JK Products & Services. Rates and charges for repairs must comply with JK Products & Services allotment policy. Lifetime warranty applies only to main frame super structure. Refer to the Operation/Instruction manual for specific details. VI.

VII.

The original purchaser must complete and return the attached warranty card within ten (10) business days of receipt of equipment for coverage of potential claims under this warranty.

o warranty card is received, proof of purchase from JK Products & Services, or an authorized distributor or dealer must be provided for a claim to be considered. JK Products & Services arves the right to deny claims where proof of purchase has been provided but no warranty card was received.

This warranty does not apply to any failure of the product or any parts of the product due to alterations, use of third party or non-OEM parts, modifications, misuse, abuse, accident, improper maintenance, improper installation, or acts of God. This warranty also does not apply if:

- The serial number on the product has been removed, altered, or defaced. The serialized components of the unit do no match with other serialized components in records maintained by JK Products & Services. The serial number or serialized components have been altered with the intent to defraud.

There are no warranties which extend beyond the description on the face hereof. There is no express or implied warranty of fitness or merchantability. The remedies provided in this limited warranty are the exclusive remedies provided to the original purchaser by JK Products & Services and are provided in substitution of all other remedies. Consequential and incidental damages are excluded

No person, firm, or corporation is authorized to obligate JK Products & Services for any liability in connection with the sale or use of these goods.

JK Products & Services

One Walter Kratz Drive

Jonesboro, AR 72401
B70.935.1130

800.643.0086

℅ Detach Here ℅

Studio/Salon Name:				
Contact Name:			TANNING SYSTEM	ACCESSORY 1
Street Address:			Affix Serialized	Affix Serialized
City:	State:	Zip:	Label Here	Label Here
Telephone:[]	Start-Up	Date:		
JK Distributor/Affiliate:				
				ACCESSORY 2
				Affix Serialized Label Here
Indicate below that each the tanning system are	h of the task below have been co in working order:	mpleted/that the aspects of		Laber nere
Lamps:	Features/Options:	Training:		
Body	Skin Sensor	Basic Operation	Please indicate (by marking an X) on the ap any damage to the tanning system	oplicable illustration
Base	Air Conditioning	□ Accessing Lamps		
Canopy	□ Aqua Mist	□ Location/Access		
□ Facial Lamps	Aroma	Filters		
□Shoulder Tanner	□ Audio System	Explanation of		
Decor		Features		
	Missing Components:	Settings/Adjustments:		
	🗆 Manuals	🗆 Audio		
	□ Hardware	□ Springs	=	
	□ Accessories	Network		
By signing below, you c	onfirm that the listed equipment	t was delivered to the		
	d, and was recieved in full and s			
			Comments:	
Signature, JK Dist./	Affiliate Date	9	comments	
	alon Representative Date			
	alon Representative Date			

Α

75
75
64
28
17
53

В

Bed base.....67

С

Canopy panel	65
Chip card replacement	68
Cleaning53, 5	4, 58
Air conditioning	77
Air conditioning filter	77
Filter	75
Filter mat	76
Lamps, filter panels	59
Cleaning or replacing lamps	
Base	72
Canopy	73
Cleaning/disinfection	
Cleaning intervals	60
Commissioning	19
Customer Service	2

D

Decommissioning	80
Definitions	6
Device description	12
Dimensions	30
Disinfection53, 54	, 58
Disposal	80

Ε

Electrical specifications	.28
EMC information	.86
Empty the condensation tank	.77
Export	.11

F

Facial tanner
Maintenance intervals 56, 61
Filter
Cleaning75, 76
Filter panels71
Maintenance intervals 56, 61
Foreseeable misuse40
Functions48

G

Η

High pressure lamps,	
fire hazard7	1

I

Installation location	17
Intended use	35
Interior lights	74

L

Lamp configuration	.31
Lamps, replacing	.68
Low pressure lamps	.69

Μ

Makrolon tubes70

Ν

Noise level28

0

Obligations of the	
studio operator	40
Operating altitude	18
Order numbers	31, 34

Ρ

81
58
28
36

R

Recycling8	60
------------	----

S

Safety measures during	
maintenance work	55
Scope of delivery	11
Service kit	63
Setup location	18
Skin condition	35
Skin types	45
Spare parts	56, 61
Order numbers	34
Staff training	40
Starter	31, 70
Storage	80

Т

Tanning times	46
Technical data	28
Transport	16
Troubleshooting	83

U

UV lamps	
Control	31
Power rating	31

۷

Ventilation	. 17
-------------	------